

ADEMCO LIMITED WARRANTY

Alarm Device Manufacturing Company, a Division of Pittway Corporation, and its divisions, subsidiaries and affiliates ("Seller"), 165 Eileen Way, Syosset, New York 11791, warrants its products to be in conformance with its own plans and specifications and to be free from defects in materials and workmanship under normal use and service for 18 months from the date stamp control on the product or, for products not having an Ademco date stamp, for 12 months from date of original purchase unless the installation instructions or catalog sets forth a shorter period, in which case the shorter period shall apply. Seller's obligation shall be limited to repairing or replacing, at its option, free of charge for materials or labor, any product which is proved not in compliance with Seller's specifications or proves defective in materials or workmanship under normal use and service. Seller shall have no obligation under this Limited Warranty or otherwise if the product is altered or improperly repaired or serviced by anyone other than Ademco factory service. For warranty service, return product transportation prepaid, to Ademco Factory Service, 165 Eileen Way, Syosset, New York 11791.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. IN NO CASE SHALL SELLER BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, OR UPON ANY OTHER BASIS OF LIABILITY WHATSOEVER, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

Seller does not represent that the products it sells may not be compromised or circumvented; that the products will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the products will in all cases provide adequate warning or protection. Customer understands that a properly installed and maintained alarm may only reduce the risk of a burglary, robbery, fire or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result. CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE OR OTHER LOSS BASED ON A CLAIM THE PRODUCT FAILED TO GIVE WARNING. HOWEVER, IF SELLER IS HELD LIABLE, WHETHER DIRECTLY OR INDIRECTLY, FOR ANY LOSS OR DAMAGE ARISING UNDER THIS LIMITED WARRANTY OR OTHERWISE, REGARDLESS OF CAUSE OR ORIGIN, SELLER'S MAXIMUM LIABILITY SHALL NOT IN ANY CASE EXCEED THE PURCHASE PRICE OF THE PRODUCT, WHICH SHALL BE THE COMPLETE AND EXCLUSIVE REMEDY AGAINST SELLER. This warranty replaces any previous warranties and is the only warranty made by Seller on this product. No increase or alteration, written or verbal, of the obligations of this Limited Warranty is authorized.

REFER TO THE INSTALLATION INSTRUCTIONS FOR THE CONTROL PANEL WITH WHICH THIS DEVICE IS USED, FOR DETAILS ON LIMITATIONS OF THE ENTIRE ALARM SYSTEM



ALARM DEVICE MANUFACTURING COMPANY
A DIVISION OF PITTPWAY CORPORATION

165 Eileen Way, Syosset, New York 11791

Copyright © 1993 PITTPWAY CORPORATION



No. 5800TM
TRANSMITTER MODULE
used with
No. 5827BD Wireless Bidirectional Console

INSTALLATION INSTRUCTIONS**GENERAL INFORMATION**

The No. 5800TM Transmitter Module is designed to be used in conjunction with one or more No. 5827BD Wireless Bidirectional Consoles. The 5800TM is compatible with any control panel that is *also* equipped with a 4281 type (5700 System) or 5881 type (5800 System) RF receiver. It complements the RF receiver in that it transmits the information to be displayed on, or sounded by, the 5827BD(s). No modification to the control is necessary. Connections are made directly to the control's console connection points, as described below.

See the installation instructions that accompany the 5827BD for complete operating information for the 5800TM/5827BD combination.

INSTALLATION

Observe the same precautions in selecting a location for the 5800TM as for the system's 4281 or 5881 RF receiver, to insure good transmission and reception. *The 5800TM must be located next to the system's receiver (between one and two feet from the 4281/5881's antennas).*

Do not install the 5800TM within the system control panel's cabinet. Mount it remotely, on its accompanying mounting bracket. The bracket is easily installable via two countersunk mounting holes. Keyhole slots on the rear of the 5800TM slip onto two hooks on the mounting bracket.

PROGRAMMING

For an Addressable System:

1. **Select one of the following addresses for the 5800TM by removing its cover, and cutting the appropriate jumper(s) on its circuit board, as follows:**

FOR ADDRESS	CUT JUMPER(S)
28	RED (W1)
29	WHITE (W2)
30	BOTH

2. **Program the control panel**, by assigning the address selected above to one of the wired consoles in the system.

Note: For those controls requiring device programming (in #93 mode), program this device as an "Alpha Console."

For a Non-Addressable System: No programming is required.

WIRING CONNECTIONS

Connect the 5800TM to the control panel's remote console connection points, using the supplied connector with flying leads. Wire colors and functions match those for consoles:

RED: +12VDC
BLACK: Ground
GREEN: Data to Control Panel
YELLOW: Data from Control Panel
BLUE: Not used

SPECIFICATIONS

Physical: 2-1/4" W x 4-1/8" H x 7/8" D (57mm x 105mm x 22mm)

Electrical: Voltage: 12VDC (from control's remote console connection points)

Current: 20mA