

Basics of Programming

1.	To enter programming enter the installer code (4112) + 8 + 0 + 0, screen displays "INSTALLER CODE 20"
2.	To change the values of the memory location press "*" & the location number (ex. *20) then enter the desired values.
3.	To view the values in any of these locations press "#" and the location number (ex. #20) & the entered digits will be read back to you on the keypad screen.
4.	To enter the zone programming menu mode press "*" + 56, screen displays "ENTER ZN NUM. (00 = QUIT)" Press "*" to move to the right or the "#" key to move to the left & make changes as needed.
5.	To exit the zone programming menu mode at the "ENTER ZN NUM. (00 = QUIT)" enter 00, screen displays "EXIT ERROR RPT 59"
6.	To enter the expert zone programming mode press "*" + 58, screen displays: ZN ZT P - RC IN : RT(L) 01 09 1 - 10 HW : 1 ZN = the zone number, ZT = Zone Response Type, RC = Report code, P = Partition number, IN = Input type, RT = Response time, & L = Loop number. To move around in this field press "*" to move to the ZT press the "A" key moves to the right, the "B" key moves to the left, Press "*" to enroll the serial number for wireless zones & change the loop number or "C" to copy the previous zones serial number. Make changes as needed.
7.	To exit the expert mode enter 00 when the cursor is flashing under the ZN, screen displays "EXPERT MODE 58".
8.	To enter the Relay/X10 program mode press "*" + 80, screen displays "ENTER DEVICE NO. (00 = QUIT) 01" press the "*" key to move to the right or the "#" key to move to the left & make changes as needed.
9.	To exit relay programming enter 00 at the "ENTER DEVICE NO. (00 = QUIT)" prompt, screen displays "OUTPUT DEVICES ENTER * 80"
10.	To enter zone list programming press "*" + 81, screen displays "ZONE LIST NO. (00 = QUIT) 01". Press the "*" key to move to the right or the "#" key to move to the left and make changes as needed.
11.	To exit Zone list programming press 00 at the "ZONE LIST NO. (00 – QUIT) prompt, screen displays "SWINGER SUPPRESS 81"
12.	To exit the program mode and re-enter using the Installer Code + 8 + 0 + 0 method press "*" + 99.
13.	To exit the program mode without allowing access back in unless powering down then up and depressing the * + # simultaneously press "*" + 98.